



Replace bearing

Machine new fan shaft

Remove
4' diameter
fan wheel from
damaged fan
shaft